

SAMSUNG

REFRIGERATOR

BOTTOM MOUNT FREEZER

MODEL NAME : RF263TEAE
RF263BEAE****

SERVICE *Manual*

REFRIGERATOR



CONTENTS

- 1. PRECAUTIONS (SAFETY WARNINGS).....4
- 2. PRODUCT SPECIFICATIONS.....8
- 3. DISASSEMBLY AND REASSEMBLY25
- 4. TROUBLESHOOTING50
- 5. PCB DIAGRAM.....95
- 6. WIRING DIAGRAM100
- 7. SCHEMATIC DIAGRAM101



WARNING

IMPORTANT SAFETY NOTICE

The service guide is for service men with adequate backgrounds of electrical, electronic, and mechanical experience.

Any attempt to repair a major appliance may result in personal injury and property damage.

The manufacturer or dealer cannot be responsible for the interpretation of this information.

SAMSUNG ELECTRONICS AMERICA, INC.

Technical Service Guide

Copyright ©2012

All rights reserved. This service guide may not be reproduced in whole or in part in any form without written permission from the SAMSUNG ELECTRONICS Company.

Contents

1. Precautions (safety warnings)	4
2. Product specifications	8
2-1) Introduction of Main Function	9
2-2) Specifications	11
2-3) Interior Views	12
2-4) Model Specification & Specification Chart	13
2-5) Dimensions of Refrigerator (Inches)	16
2-6) Optional Material Specification	17
2-7) Refrigerant Route in Refrigeration cycle	18
2-7-1. Principle of freezeer	19
2-7-2. Operation theory of refrigeration cycle components	20
2-7-3. Refrigeration Cycle Type	23
2-8) Cooling Air Circulation	24
3. Disassembly and Reassembly	25
3-1) PRECAUTION	26
3-2) Refrigerator Door	27
3-3) Door Handle Refrigerator	29
3-4) Door Handle Freezer	29
3-5) Refrigerator Light	30
3-6) Cover-Display & Water-Dispenser	30
3-7) Water-Dispenser	31
3-8) Glass Shelf	32
3-9) Foldable Glass Shelf	32
3-10) Vegetable & Fruit Drawers Shelf	33
3-11) Case Water Filter	34
3-12) Cool Select Pantry	35
3-13) Motor Damper	35
3-14) Water Filter (Assembly & Disassembly)	36
3-15) Gallon Door Bin	37
3-16) Vertical Hinged Section	37
3-17) Evaporator Cover In Refrigerator	38
3-18) Evaporator In Refrigerator	39
3-19) Freezer Door	40
3-20) Ice-Maker	41
3-21) Auger Motor Fan	43
3-22) Freezer Light	44
3-23) Door Switch In Freezer	44
3-24) Evaporator Cover In Freezer	45
3-25) Evaporator In Freezer	45
3-26) Machine Compartment	46
3-27) COMPRESSOR	48
3-28) Electric Box	49
4. Troubleshooting	50
4-1) Function for failure diagnosis	51
4-2) Diagnostic method according to the trouble symptom(Flow Chart)	62

Contents

4-2) Diagnostic method according to the trouble symptom(Flow Chart).....	63
INVERTER PCB Circuit Diagram.....	94
5. Pcb Diagram	95
5-1) PCB Layout with part position	96
5-2) PCB Layout with part position (Inverter Board).....	97
5-3) Connector Layout with part position (Main Board)	98
5-4) Connector Layout with part position (Inverter Board).....	99
6. Wiring Diagram	100
6-1) Model : RF263TEAE**, RF263BEAE**	100
7. Schematic Diagram	101
7-1) Whole block diagram	101
7-2) Whole block diagram.....	102
7-3) CIRCUIT DIAGRAM.....	103
7-3-1. Main	103
7-3-2. INVERTER.....	104

1. PRECAUTIONS (SAFETY WARNINGS)

- ☒ Unplug the appliance before replacing or repairing electrical parts.
 - ☒... Be careful to avoid electric shock.
- ☒ Always use only the correct replacement parts.
 - ☒...Check the model, rated voltage, rated current and running temperature rating.
- ☒ When troubleshooting, verify that wiring harnesses are connected securely.
 - ☒...Make sure the connectors are not separated when power is supplied.
- ☒ Check for visible traces of water on electrical parts.
 - ☒...Replace or secure any part that may have come in contact with water.
- ☒ Check the status of parts after replacement or troubleshooting.
 - ☒...All parts must be reinstalled properly.
- ☒ Check the location where the refrigerator will be used.
 - ☒...If the refrigerator will be used in a damp or wet space, or if installation will be unstable, the unit should be relocated.
- ☒ The refrigerator must be grounded properly.
 - ☒...An earth ground should be used if there is a risk of high humidity or wetness.
- ☒ The refrigerator should be plugged into a dedicated outlet.
 - ☒...Make sure the power cord is not damaged, crushed, squeezed or burned.
- ☒ If the plug is damaged it should be replaced.
 - ☒...If the socket is damaged, it should not be used.
- ☒ Consumers must not try to repair the refrigerator.
- ☒ Nothing should be stored in the refrigerator except food.
 - ☒...Drugs requiring precise temperatures should not be stored in the refrigerator
 - ☒...Flammable substances (alcohol, benzene, ether, LP gas, etc.) carry risk of explosion and should not be stored in the refrigerator.

PRECAUTIONS (SAFETY WARNINGS)

Read all instructions before repairing the product and follow the instructions in order to prevent danger or property damage.
Plug out and remove all the items in refrigerator prior to repair.

CAUTION/WARNING SYMBOLS DISPLAYED



Warning

Indicates that a danger of death or serious injury exists.



Caution

Indicates that a risk of personal injury or material damage exists.

SYMBOLS



means "Prohibited".



means "Do not disassemble".



means "No contact".



means "Warning or Caution".



means "Unplug the unit before preforming service"



means "Earth or Ground".




Warning & Caution

Unplug to exchange the interior lamp.

- It may cause electric shock.



Unplug




Use the rated components on the replacement.

- Check the correct model, rated voltage, rated current, operating temperature and so on.




On repair, make sure that the all wiring harnesses are reconnected Wiring harnesses should be connected tightly and kept dry.

- Bundle tightly wires in order not to be detached by the external force and then not to be wetted



On repair, make sure that all parts and wires are free of dust and debris

- Cleaning parts could prevent fire or shorting.




Check the status of parts after replacement or troubleshooting.

- All parts must be reinstalled properly.



Check for visible traces of water on electrical parts

- Replace or secure any part that may have come in contact with water.




☒ Please let users know following warnings & cautions in detail.



Warning & Caution

Customers should not store glass bottles of liquid in the freezer section. Frozen bottles could explode and cause injury.



Customers should not store narrow or long bottles or food in a small door shelf.

• These items could fall when the door is opened, causing injury to the customer.



Drugs requiring precise temperatures should not be stored in the refrigerator.




The refrigerator should be plugged into a dedicated outlet.

• Multiple plugs in the outlet could cause excessive heat or fire.



Prohibited




Consumers must not try to repair the refrigerator.

• Electrical and mechanical parts could injure the consumer.




Do not disassemble



Make sure the power cord is not damaged or crushed.

• A damaged cord could cause excessive heat or fire.




Customer should not store articles on the product.

• Opening or closing the door may cause things to fall down, which may cause injury,




Prohibited



Check the location where the refrigerator will be used.

• If the refrigerator will be used in a damp or wet space, or if installation will be unstable, the unit should be relocated.




The refrigerator must be grounded properly.

• An earth ground should be used if there is a risk of high humidity or wetness.




Earth




FLOORING

For proper installation, this refrigerator must be placed on a level surface of hard material that is the same height as the rest of the flooring. This surface should be strong enough to support a fully loaded refrigerator, or approximately 152KG (335LB).



MOVING

Protect the finish of the flooring. Cut a large section of the cardboard carton and place under the refrigerator where you are working. When moving, be sure to pull the unit straight out and push back in straight.











2. PRODUCT SPECIFICATIONS

2-1) Introduction of Main Function.....	9
2-2) Specifications.....	11
2-3) Interior Views	12
2-4) Model Specification & Specification Chart.....	13
2-5) Dimensions of Refrigerator (Inches).....	16
2-6) Optional Material Specification.....	17
2-7) Refrigerant Route in Refrigeration cycle.....	18
2-7-1. Principle of freezer.....	19
2-7-2. Operation theory of refrigeration cycle components	20
2-7-3. Refrigeration Cycle Type	23
2-8) Cooling Air Circulation.....	24

2-1) Introduction of Main Function

- A newly developed SAMSUNG bottom mount freezer in 2012 has the following characteristics.

	<p>Surround Multi Flow</p> <ul style="list-style-type: none"> • Provides uniform cooling for each shelf and every corner in the fresh food section. This is accomplished by using a center positioned fan and duct with multiple cooling flow openings.
	<p>Twin Cooling System</p> <ul style="list-style-type: none"> • The refrigerator and the freezer each have an evaporator. Given this independent system, the freezer and the refrigerator are cooled individually as required and are, therefore, more efficient. Food odor from the refrigerator does not affect food in the freezer due to separate air flow circulation.
	<p>Electronic control from outside of Pantry Cover(RF263TEAE**,RF323BEAE**)</p> <ul style="list-style-type: none"> • Adjustable temperature control ((around 41 ™ (5 ™) : Deli / around 38 ™ (3 ™) : Fresh / around 34 ™ (1 ™) Chilled) Temperature control from outside of the Pantry : user friendly design helps keep foods fresh for longer
	<p>One Lever Dispenser</p> <ul style="list-style-type: none"> • One lever dispenser easily switches between ice and water.
	<p>Secure Auto Close Door System</p> <ul style="list-style-type: none"> • Door close tightly. • Food on the doors stays cool. • Prevents moisture from forming on the outside of the doors.
	<p>Easy Handle System</p> <ul style="list-style-type: none"> • Ez-open Freezer Door • Ergonomic Door Design

	<p>Slim Water Filtration System</p> <ul style="list-style-type: none"> • Slim water filter is placed between crispers for convenient filter replacement without removing items from Refrigerator.
	<p>Dual Ice Maker</p> <ul style="list-style-type: none"> • 9 cubes ice-Maker(Refrigerator) • 7 cubes ice-Maker(Freezer) <p>FOR RF263TEAE**</p>

2-2) Specifications

ELECTRICAL SPECIFICATIONS


Defrost Control.....From 12 to 30hrs(comp. run time)
 Thermo Bimetal Protector ...140°F(60°C)(off) 104°F(40°C)(on)
 Defrost Thermistor(502AT).....50°F(10°C)(off)
 Electrical Rating..... AC115V 60Hz 11.6 Amps
 Maximum Current Leakage..... 0.25 mA
 Maximum Ground Path Resistance.....0.1 Ohm
 Energy Consumption..... 481 kWh/year

NO LOAD PERFORMANCE

Refrigerator,°F 44°F(7°C) ~ 34°F(1°C)
 Freezer,°F..... 5°F(-15°C) ~ -8°F(-23°C)
 Run Time,% < 40< 80

REFRIGERATION SYSTEM


Refrigerant Charge (R134a).....5.64 oz(160g)
 Compressor MSV172AL-2J
 Compressor oilFreol 5 \propto 15c
 R Capillary tube(Dia, Length)..... 0.032 ",118"(0.82mm,3500mm)




INSTALLATION

Clearance must be provided for air circulation
 AT TOP..... 1" (25 mm)
 AT SIDES..... 1" (25 mm)
 AT REAR 2" (50 mm)


Refrigerator





Freezer



2-3) Interior Views






2-4) Model Specification & Specification Chart

ITEM	Model		RF263TEAE**	RF263BEAE**
			ICE&WATER DISPENSER WITH PANTRY& TWIN ICE	ICE&WATER DISPENSER WITH PANTRY
	IMAGE			
External size	W		35 3/4 Inch (908mm)	35 3/4 Inch (908mm)
	D	On Cabinet	29 1/8 Inch (739mm)	29 1/8 Inch (739mm)
		W/O Handle	32 7/8 Inch (836mm)	32 7/8 Inch (836mm)
		With Handle	35 5/8 Inch (905mm)	35 5/8 Inch (905mm)
	H	W/O Hinge Cap	68 5/8 Inch (1744mm)	68 5/8 Inch (1744mm)
		With Hinge Cap	70 Inch (1778mm)	70 Inch (1778mm)
Net Capacity	Total		25.6(725.2ℓ)	25.6(725.2ℓ)
	Freezer		7.9(222.6ℓ)	7.9(222.6ℓ)
	Refrigerator		17.8(503.0ℓ)	17.8(503.0ℓ)
Efficiency of Volume			55.40%	55.40%
Weight	Set		140kg	140kg
	Packing		152kg	152kg
Packing	Width		38 5/8 Inch (980mm)	38 5/8 Inch (980mm)
	Depth		36 4/8 Inch(920mm)	36 4/8 Inch(920mm)
	Height		75 3/4 Inch (1923mm)	75 3/4 Inch (1923mm)
Compressor			RECIPROCATE	RECIPROCATE
Rated Frequency and Frequency			AC 115V/60Hz	AC 115V/60Hz
Refrigerant			R134a	R134a
Foaming Agent			C-PENTANE	C-PENTANE
Refrigerant Input Amount			5.29 oz (160g)	5.29 oz (160g)
Type Refrigerator			INDIRECT COOLING METHOD REFRIGERATOR	INDIRECT COOLING METHOD REFRIGERATOR
Motor Rated Consumption Power			140W	140W
Electric Heater Rated Consumption Power			517.8W	517.8W





Items			Specification	
Model			RF263TEAE** / RF263BEAE**	
Components for Freezer	Compressor	Model	MSV172AL2J/SM1	
		Starting type	BLDC	
		Oil Charge	FREOL α - 15c	
	Evaporator	Freezer	SPLIT FIN TYPE	
		Refrigerator	SPLIT FIN TYPE	
	Condenser		Forced and Natural Convection Type	
	Dryer		Molecular sieve XH-9	
	Capillary tube (Dia x Length)		R:0.032" (0.082mm x 3500mm)	
	Refrigerant		R134a	
Room Temperature Sensor Components	Freezer	Model	Temperature Selection	On(°F) Off(°F)
		THERMISTOR (F-SENSOR)	-8°F (-23°C)	-5°F (-21°C) -11°F (-24°C)
			-0°F (-18°C)	3°F (-16°C) -3°F (-19°C)
			5°F (-15°C)	8°F (-12°C) 2°F (-17°C)
	Refrigerator	Model	Temperature Selection	On(°F) Off(°F)
		THERMISTOR (R-SENSOR) 502AT	34°F (1°C)	36°F (2°C) 32°F (0°C)
			37°F (3°C)	39°F (4°C) 35°F (2°C)
			44°F (7°C)	46°F (8°C) 42°F (6°C)
Defrost Related Components	Defrost Cycle	First Defrost Cycle (Concurrent defrost of F and R)		6hr ± 10min
		Defrost Cycle (FRE)		12~30hr (vary according to the conditions used)
		Defrost Cycle (REF)		6~15hr (vary according to the conditions used)
		Pause Time		12 ± 1min
	Defrost Sensor	F Defrost-Sensor	Model	THERMISTOR (502AT)
			SPEC	5.0 Ω at 77°F (25°C)
		R Defrost-Sensor	Model	THERMISTOR (502AT)
			SPEC	5.0 Ω at 77°F (25°C)
	Bimetal	F Bimetal-thermo Protector	Rated	AC 125V, 6A
			Operating temperature	Off : 140°F (60°C) / On : 104°F (40°C)
		R Bimetal-thermo Protector	Rated	AC 125V, 6A
			Operating temperature	Off : 140°F (60°C) / On : 104°F (40°C)

Items			Specification
Model			RF263TEAE** / RF263BEAE**
Electric Components	Defrost Heater (FRE)	Heated at F Defrost	AC 120V, 240W
	Defrost Heater (REF)	Heated at R Defrost	AC 120V, 120W
	DISPENSER Heater	Interlock with French Heater	AC 120V, 2.5W
	FRENCH Heater	—	AC 120V, 10W
	ICE Duct Heater	Drain Heater (FRE)	DC12V, 2W
	Water Tank Heater	Drain Heater (REF)	DC12V, 2.3W
	Bimetal thermo for Preventing Overheating of Refrigerator Lamp		AC 125V 6A / AC 350V 3A Off : 140°F (60°C) / On : 104°F (40°C)
	Over Load Relay	Model	4TM445PHBYY-82
		Temp. ON	156.2 ± 16.2°F (69 ± 9°C)
		Temp. OFF	257 ± 9°F (125 ± 5°C)
	Rated Voltage		AC 115V/60Hz
	Motor-BLDC (FRE)		DC12V / DREP5020LC
	Motor-Brushless DC Box Fan		DC12V 0.1A / 2606JL-04W-S39-UQ1
	Motor-Brushless DC Box Fan		DC12V 0.3A / 3612JL-04W-S49-G51
	Motor-BLDC(CIRCUIT)		DC12V 0.14A / DRCP8020LA
	Motor-DAMPER(PANTRY)		DC12V / NSBY001TK1
	Lamp LED (FRE)		DC12V / 85~130mA
	Lamp LED (REF)		DC12V / 510~780mA
	Lamp LED (VEG)		DC 12V, 95~145mA
	Door Switch	FRE	AC 125V 1.5A (1EA)
		REF	DC200V 1.5A / MS-406-SS-01 (2EA)
		REF (ICE ROOM)	125~250v / 5A, PARKEco
	Power Cord		AC 125V 15A
	Earth Screw		BSBN (BRASS SCREW)

2-5) Dimensions of Refrigerator (Inches)




2-6) Optional Material Specification

Image	Part Name	Part Code	AMOUNT
	FILTER WATER-ASSY	DA29-00019A	1
	FIXER HANDLE WRENCH SPANNER ASSY LABEL HANDLE INSTRUCTION * The components are included in Assy Cushion Handle	DA61-03734A DA80-00026B DA99-03429J	4 1 1
	LED LAMP REF	DA41-00676G	4
	LED LAMP CASE-VEG R, L	DA47-00519S	1



PRODUCT SPECIFICATIONS

2-7) Refrigerant Route in Refrigeration cycle

Compressor → Condens → Hot Pipe → Dryer → Capillary Tube → Refrigerator Evaporator
→ Pipe Direct Ice → Freezer Evaporator → Suction Pipe → Compressor



2-7-1. Principle of freezer



2-7-2. Operation theory of refrigeration cycle components

☒ Condenser

1) Role: A device which radiates heat to the outside of the refrigerator. As this heat is dispersed, the high temperature / high pressure vapor refrigerant changes to a liquid state.

2) Types

A. Air-cooling Type : Condense air by circulating naturally or manually.

1) Natural Convection Type : Used for the household refrigerator which has small condensing capacity.

2) Manual Convection Type : Circulate air manually (Large capacity)

B. Water-cooling Type : Make cooling water pass through the pipe in the condenser (Large capacity)

☒ Location

① CLUSTER heat-radiating type : All Pipes effective for radiating heat are formed in the right/left, and front side of refrigerator with hard urethanes and radiate heat through the whole surfaces of cabinet to ambient air.

② Install the condenser on the outside of the product. (An old model)

③ Make them cluster at the lower part of product and radiate heat manually by fan.

☒ Radiate condensed potential heat up to liquefy completely and make change the state without changing the gas temperature itself.

☒ Pipe thickness

① Low pressure: 6.3mm ② High pressure : 4.7mm ③ Capillary : About 0.4-0.8mm

☒ Condenser length (Based on 300ℓ): 26.5 M

① Assistance : 5 M ② HOT-PIPE: 6.6 M ③ CLUSTER-PIPE: 4.17 M

☒ Capillary

1. Role: A device which makes low temperature and pressure refrigerant by reducing the pressure the normal temperature / high pressure liquid refrigerant condensed from condenser, and supply it to the evaporator.

A. To evaporate more lower temperature in case of evaporation.

B. It flows to the evaporator without back flowing to condenser, if compressor stops, and the difference of pressure between high pressure and low pressure is small so it is easy to operate the compressor again.

2. Outline

A. Thickness : About 0.4-0.8mm

B. Length : It is changeable to low temperature and pressure (10^{-5} Pa/°C) depends on the 2M of thin and long copper pipe wall resistance.

■ Evaporator

1. Role: As the low pressure liquid refrigerant flowed from capillary absorbs heat inside of the refrigerator, it becomes low pressure gas and refrigerate the foods.
2. Theory: The low pressure refrigerant flowed to evaporator operates cooling which takes ambient evaporated potential heat with maintaining the evaporation up to evaporate completely.
3. Types of Evaporator
 - A. ROLL-BOND Evaporator → Direct Cooling ONE-DOOR Type
 - ☞ Rolled and adhere the 2 aluminum plate and then make refrigerant passage.
 - B. PIN-PIPE Type → Indirect cooling TWO-DOOR Type
 - ☞ a small aluminum plate on the aluminum pipe to increase the cooling effect.

■ Compressor

1. Role: It operates same as pump which pull out the subterranean water. It inhales the low temperature and pressure refrigerant gas (flowed out) from evaporator and make high temperature and pressure refrigerant liquid in the compressor and send it to the condenser.
2. Type of Condenser
 - a. Back-and-forth motion type: A method that piston makes back-and-forth motion through shaft and cylinder of motor rotation and compresses. ※ Used for household refrigerant
 - b. Rotary Type: A method that inhales the refrigerant gas through the gap between the outside of rotor electric attached on the shaft and the inside of cylinder and compresses.
 - c. Centrifugal Type
3. Please insert the explanation of inverter comp operation theory.

■ Dryer

1. Role: Absorb the moisture from the refrigerant that refrigeration cycle circulates and eliminate the foreign substance.
2. Structure: If even some moisture is included refrigerant is impossible to circulate by freezing the small capillary outlet, so silica gel or molecular sieve is (included and) sealed to absorb the internal moisture, and install a minute net to eliminate the foreign substance.

PRODUCT SPECIFICATIONS

※ . Influence of moisture

- ① Moisture precipitation - Blocked by ice
- ② Refrigerant and reaction
- ③ Life reduction of oil
- ④ Acceleration of oxidization
- ⑤ Copper plating phenomenon
- ⑥ Gas dissolution by the interaction of synthetic insulating material (insulator)

※ . Influence of foreign substance

- ① Increase of condensed temperature.
- ② Increase of temperature.
- ③ Decrease of cooling efficiency
- ④ Shorten the life by friction between oil and foreign substance in the compressor.


■ Accumulator

- 1. Role : To send a pure refrigerant gas to compressor by removing completely the refrigerant liquid from evaporator.

※ If a refrigerant liquid go into the compressor, overload is occurred.

2-7-3. Refrigeration Cycle Type


HM Cycle




PRODUCT SPECIFICATIONS

2-8) Cooling Air Circulation

Refrigerator



Freezer







3. DISASSEMBLY AND REASSEMBLY

3-1) PRECAUTION	26
3-2) Refrigerator Door	27
3-3) Door Handle Freezer.....	29
3-4) Refrigerator Light	30
3-5) Cover-Display & Water-Dispenser	30
3-6) Water-Dispenser	31
3-7) Glass Shelf.....	32
3-8) Foldable Glass Shelf.....	32
3-9) Vegetable & Fruit Drawers Shelf	33
3-10) Cool Select Pantry	34
3-11) Motor Damper	34
3-12) Case Water Filter.....	35
3-13) Water Filter (Assembly & Disassembly)	36
3-14) Gallon Door Bin	37
3-15) Vertical Hinged Section.....	37
3-16) Evaporator Cover In Refrigerator.....	38
3-17) Evaporator In Refrigerator	39
3-18) Freezer Door.....	40
3-19) Pull Out Drawer	41
3-20) Ice-Maker	42
3-21) Freezer Light.....	43
3-22) Door Switch In Freezer	43
3-23) Evaporator Cover In Freezer.....	44
3-24) Evaporator In Freezer	44
3-25) Machine Compartment.....	45

3-1) PRECAUTION

- Unplug the refrigerator before cleaning and making repairs.
- Remove any foreign matter or dust from the power plug pins.
 - Otherwise there is a risk of fire.
- Do not use a cord that shows cracks or abrasion damage along its length or at either end.
- Do not plug several appliances into the same multiple power board. The refrigerator should always be plugged into its own individual electrical which has a voltage rating that matched the rating plate.
 - This provides the best performance and also prevents overloading house wiring circuits, which could cause a fire hazard from overheated wires.
- Do not install the refrigerator in a damp place or place where it may come in contact with water.
 - Deteriorated insulation of electrical parts may cause an electric shock or fire.
- The refrigerator must be grounded.
 - You must ground the refrigerator to prevent any power leakages or electric shocks caused by current leakage from the refrigerator.
- Do not put bottles or glass containers in the freezer.
 - When the contents freeze, the glass may break and cause personal injury.
- Do not store volatile or flammable substances in the refrigerator.
 - The storage of benzene, thinner, alcohol, ether, LP gas and other such products may cause explosions.








- Required Tools

IMAGE	ITEM	USE
	Phillips Head Driver	Use for assembling and disassembling of screw
	Flat Head Driver	Use for assembling and disassembling of HomeBar, Dispenser, Deli Cartessen Box, Main PBA etc...
	Hex Wrench 2mm	Use for assembling and disassembling of Handle
	Socket Wrench 10mm	Use for assembling and disassembling of Door Hinge





- Water whitening phenomenon

All water provided to refrigerators flows through the core filter which is an alkaline water filter. In this process, the pressure in the water that has flowed out of the filter gets increased, and massive oxygen and nitrogen become saturated. When this water flows out in the air, the pressure plummets and the oxygen and nitrogen get supersaturated so that they turn into gas bubbles. The water could look misty due to these oxygen bubbles. It is not because dust or chemicals, just a few seconds later, it will be clean again.

3-2) Refrigerator Door




Part Name	How To Do	Descriptive Picture
Refrigerator Door	<p>1. Remove the 3 screws holding down the Top Table and remove the Top Table (1)</p>	
	<p>2. Disconnect the electrical (2) above the upper left door hinge To disconnect the connector (2) more easily, press the end of the hook (3) and pull connector.</p> <p> CAUTION Make sure unit is unplugged.</p>	 
	<p>3. As shown in the picture, remove water tube from hinge (4) by holding at the both sides of the Tube Fitting and pulling it out. And, remove the Tube Fitting (5) by pulling the water hose after pushing in the locking ring tab at the end of the Tube Fitting.</p>	 
	<p>4. After pulling the Hinge Lever, remove the Hinge.</p>	

3-2) Refrigerator Door




Part Name	How To Do	Descriptive Picture
Refrigerator Door	<p>5. Lift the door straightly up to remove.</p> <p> CAUTION Be careful not to drop the door.</p>	
	<p>6. Lift the grommet hinge straightly up to remove.</p>	
	<p>7. With a Philips head screwdriver, remove the screw (6) attached to the lower left and right door hinges. With a 0.4in Hex wrench, remove the 2 flat head screws (7) Remove the lower left and right door hinges (8).</p>	

DISASSEMBLY AND REASSEMBLY



3-3) Door Handle Refrigerator

Part Name	How To Do	Descriptive Picture
Door Handle Fridge	1. Loosen the Set Screw situated at the end of the inner part of handle about 0.1in by using Hex wrench.	
	2. Pull the Set handle out by moving it straight down.  CAUTION Be careful not to scratch or break the parts.	




3-4) Door Handle Freezer

Part Name	How To Do	Descriptive Picture
Door Handle Freezer	1. Loosen the Set Screw situated at the bottom right of the appliance about 0.1in by using Hex wrench.	
	2. Pull the Set handle out by moving it to the left side.  CAUTION Be careful not to scratch or break the parts.	






3-5) Refrigerator Light

Part Name	How To Do	Descriptive Picture
Refrigerator Light	1. Press the tabs on the back of the Lamp Cover and take it off.	
	2. Remove the 2 screws And separate the LED panel.	

3-6) Cover-Display & Water-Dispenser


Part Name	How To Do	Descriptive Picture
Cover-Display	1. Remove a screw under the display cover.	
	2. Remove the display cover by pulling it up.	
	3. Disengage the housing connector of display cover.	

3-7) Water-Dispenser


Part Name	How To Do	Descriptive Picture
Water-Dispenser	1. Disengage the Housing Connector by pushing a flat-blade screwdriver.	
	2. Remove 2 screws of the Case Ice Route Assy.	
	3. Pull the Case Ice Route Assy.	
	4. Assembly shall be in order from the disassembly. Case-Ice and Route shall be assembled inside of hose. Otherwise, assemble cannot be accomplished.	
	5. When assembling Cover-Display, first insert it from leftside and then assemble to rightside. Otherwise, the hook can be broken.	

DISASSEMBLY AND REASSEMBLY

3-8) Glass Shelf




Part Name	How To Do	Descriptive Picture
Glass Shelf	Remove the shelf by lifting the front part of the shelf up and pulling it out.	

3-9) Foldable Glass Shelf








Part Name	How To Do	Descriptive Picture
Foldable Glass Shelf	Remove 2 screws of the Folderble Glass Shelf	

DISASSEMBLY AND REASSEMBLY

3-10) Vegetable & Fruit Drawers Shelf




Part Name	How To Do	Descriptive Picture
Vegetable & Fruit Drawers Shelf	1. Remove the vegetable & fruit drawer	
	2. Push the button on the left side of the shelf and lift up to release from the Assembly. (Refer to the picture)	
	3. Remove the vegetable & fruit drawer shelf by pulling it out. (Refer to the picture)	

3-11) Case Water Filter



Part Name	How To Do	Descriptive Picture
Case Water Filter	To disassemble the Case Water Filter, remove the water filter and all drawers and shelves.	
	1. a. Remove Cover Tube Fitting (1). b. Remove the water tube (blue) from the tube fitting by pushing in on the locking ring (2) and pulling out the tube.	 
	2. Remove 4 screws securing the water tubes.	
	3. a. Pull the Water blue hose out. b. Push the Tube Fitting (3) and pull the grey hose out.	
	4. Disconnect the 2 Housing connectors (4).	
	5. Lift and pull the Case Water Filter out.	

DISASSEMBLY AND REASSEMBLY





3-12) Cool Select Pantry

Part Name	How To Do	Descriptive Picture
Cool Select Pantry	1. Remove the cool select pantry by pulling the roller part and lifting it up.	
Cool Select Pantry Cover	1. Remove the cool select pantry cover by lifting the central part of the cover while pushing it to the left.	
Cool Select Pantry Shelf	1. Remove the cool select pantry shelf by lifting the front part of the shelf while pulling it.	

3-13) Motor Damper

Part Name	How To Do	Descriptive Picture
Motor Damper	1. Remove the cool select pantry. Remove the screw of motor damper part and then push the motor damper down.	
	2. Disengage 2 housing connectors from the rear motor damper. (Refer to the picture)	



3–14) Water Filter (Assembly & Disassembly)

Part Name	How To Do	Descriptive Picture
Water Filter	1. Turn the water filter count–clockwise. (Refer to the picture)	
	2. Remove the water filter by pulling it. (Refer to the picture)	
	3. Push the water filter directly.	
	4. Turn the water filter clockwise until it locked.	





 Be sure to flush the dispenser thoroughly (approx. 6 to 7 minutes), otherwise water may drip from the dispenser. This means that there is still air in the line.

DISASSEMBLY AND REASSEMBLY








3-15) Gallon Door Bin

Part Name	How To Do	Descriptive Picture
Gallon Door Bin (Right)	1. Remove the door bin by moving straight up.	
Gallon Door Bin (Left)	2. a. Remove the left door bin by moving straight up. b. Remove by moving up the left side of door bin.	





3-16) Vertical Hinged Section

Part Name	How To Do	Descriptive Picture
Vertical Hinged Section (center mullion attached to left side refrigerator door)	1. Unscrew 2 screws.	
	2. Disengage the internal housing connector of the vertical hinge.  CAUTION Before doing the above, make sure that the unit is unplugged	
	3. Remove the vertical hinged section by lifting the vertical hinge up. (Refer to the picture)	









3-17) Evaporator Cover In Refrigerator

Part Name	How To Do	Descriptive Picture
Evaporator Cover In Refrigerator	1. Remove the angle cap with a flat-blade screwdriver. (Refer to the picture)  CAUTION Be careful not to scratch or break the parts	
	2. Loosen the 4 screws, which fix the Evaporator cover	
	3. Remove the the lower part of angle mid by pulling it out and pushing it down. (Refer to the picture)	
	4. Lift up the evaporator cover.	
	5. Disconnect the 2 housing connectors. (Refer to the picture)  CAUTION Before doing the above, make sure that the unit is unplugged	








3-18) Evaporator In Refrigerator







Part Name	How To Do	Descriptive Picture
Evaporator In Refrigerator	1. Disconnect the housing connector part on left side.  CAUTION Before doing the above, make sure that the unit is unplugged.	
	2. Disconnect the housing connector on right side.	
	3. The Evaporator is soldered you will need Special equipment for solders again	

3-19) Freezer Door

Part Name	How To Do	Descriptive Picture
Freezer Door	1. Pull out the Pull Out Drawer by maximum.	
	2. After lifting the Pull Out Drawer up holding both sides, remove it at the rail system.	
	3. Remove the Tilting Pocket(I) by lifting it up	
	4. After lifting the Freezer Guard up holding both sides, remove it at the rail system.	
	5. Press the fixing hook (L & R) of rail system.	
	6. After holding and pulling out the top of Freezer Door, remove it at the rail system.	
	 CAUTION Make sure there is no scratch at the end of Sliding Rail by being dented from the floor .	




3-20) Ice-Maker

Part Name	How To Do	Descriptive Picture
Ice Maker	1. When pressing the Energy-Saver and the Fridge buttons on the Display together for 8 seconds at the same time, it will convert to the Test Mode and the entire Display function will be off.	
	2. When pressing any button within 15 seconds after it is shifted to the Test Mode, its function will change in the following order. Manual operation1 (FF) Manual operation 2 (OF-r) ->Manual defrost of fresh food compartments (rd) ->manual defrost of fresh and freezer compartments(fd)->cancel(Display all off). - Set unit to Fd for 5 minutes. This will allow for easy removal of the ice maker.	
	3. While pressing the tab on the top right side, lift up the Ice Bucket and pull it out  Be sure pull up for avoid broken the part	
	4. Remove the screw from the Wire Housing Cover.	
	5. Remove the Wire Housing Cover.	
	6. Disconnect the Ice Maker Housing Connector.	




Part Name	How To Do	Descriptive Picture
Ice Maker	7. Remove the screw from the Duct Tray-ice.	
	8. With a flat blade screwdriver, push the duct to the right and remove it from the locking tab.	
	9. With a flat blade screwdriver, pry down on the refrigerant tube to separate it from the bottom of the ice maker.	
	10. Push down the refrigerant pipe slightly and separate the refrigerant pipe and the Ice Maker Assembly completely.	
	11. While pressing the Hook, pull out the Ice Maker.	
	12. While pushing down the Duct-Tray-Ice, pull out the Ice Maker carefully and remove it. When removing the Ice Maker, be careful not to damage the grommets on the tray or the refrigerant tube. (Refer to the dotted parts on the right side photo.)	

DISASSEMBLY AND REASSEMBLY




3-21) Auger Motor Fan

Part Name	How To Do	Descriptive Picture
Auger Motor Fan	1. Disconnect the FAN-AUGER-ASSY Connector.	
	2. Hold the Hook on the bottom of the FAN-AUGER-ASSY and lift it up to make it free from the Locking Tab.	
	3. While lifting it up, take the FAN-AUGER-ASSY out of the Ice Maker Compartment.	

3-22) Freezer Light





Part Name	How To Do	Descriptive Picture
Freezer Light	1. Remove the cover Freezer lamp (1) using a flat-blade screwdriver.	
	2. Disengage the housing.  Before doing the above, make sure that the unit is unplugged out. CAUTION	

3-23) Door Switch In Freezer




Part Name	How To Do	Descriptive Picture
Door Switch In Freezer	1. Remove the freezer drawer bin by using a flat-blade(-) screwdriver.(Refer to Section 3-19 Freezer Door). Then remove the freezer light switch.	
	2. Disconnect the housing connector part.  Before doing the above, make sure that the unit is unplugged out. CAUTION	

DISASSEMBLY AND REASSEMBLY










3-24) Evaporator Cover In Freezer

Part Name	How To Do	Descriptive Picture
Evaporator Cover In Freezer	1. Loosen the 4 screws, which fix the Evaporator cover.	
	2. Lift up the evaporator cover.	
	3. Disconnect the housing connector on right and remove the evaporator cover.  CAUTION Before doing the above, make sure that the unit is unplugged	




3-25) Evaporator In Freezer

Part Name	How To Do	Descriptive Picture
Evaporator In Freezer	1. Disconnect the 2 housing connectors on right side.  CAUTION Before doing the above, make sure that the unit is unplugged	
	2. The Evaporator is soldered, you will need Special equipment for solder again .	







3-26) Machine Compartment

Part Name	How To Do	Descriptive Picture
Motor Fan	1. Unscrew 6 screws of cover compressor.	
	2. Disengage the housing connector. (Refer to the picture)  Before doing the above, make sure that the unit is unplugged	
	3. Remove the bracket of support circuit motor by lifting the bracket up and pulling it out.	
	4. Remove the spring with a flat-blade screwdriver. (Refer to the picture)  When you reassembly the spring in fan, you need add green glue for ensure the assembly	
	5. Remove the motor fan by pulling the fan out while holding the motor part. (Refer to the picture)	
	6. Unscrew 2 spring fixed in the motor.	
	7. Remove the hook of the motor cover with a flat-blade (-) screwdriver and then remove the motor.	






DISASSEMBLY AND REASSEMBLY

Part Name	How To Do	Descriptive Picture
Relay O/L	1. Disengage the housing connector.	
	2. Remove Cover Relay.	
	3. Remove the relay O/L with a flat-blade Your fingers . (Refer to the picture)	

3-27) COMPRESSOR

Part Name	How To Do	Descriptive Picture
COMPRESSOR	1. Cut off the SOLDER connecting the COMP and the CONDENSER with a Pipe Cutter. (Red-line marking points)	
	2. Cut off the SOLDER connecting the CONDENSER and the HOT PIPE with a Pipe Cutter. (Red-line marking points)	
	3. Link the COMP and the CONDENSER with a PIPE-CONNECTOR (DA81-05659A) by brazing the joint areas. 	
	4. Link the CONDENSER and the HOT PIPE with a PIPE-CONNECTOR (DA81-05659B) by brazing the joint areas. 	

3-28) Electric Box

Part Name	How To Do	Descriptive Picture
PBA Main	1. Remove the 3 screw attached to the upper left and right Case PCB Panel with a phillips screwdriver(+).	
	2. Disengage all housing connectors from the main PCB.  CAUTION Before doing the above, make sure that the unit is unplugged	
	3. Press the lower locking hook down and remove the Main PBA by pulling it out. (Refer to the picture)	
PBA SMPS	1. Remove the SMCS PCB by lifting the upper part of the hook up.	

4. TROUBLESHOOTING


4-1) Function for failure diagnosis.....	49
4-2) Diagnostic method according to the trouble symptom(Flow Chart).....	60
4-2) Diagnostic method according to the trouble symptom(Flow Chart).....	61
INVERTER PCB Circuit Diagram.....	92

4-1) Function for failure diagnosis

4-1-1. Test mode (manual operation / manual defrost function)

- If Energy Saver Key + Fridge Key on the front of panel are pressed simultaneously for 8 seconds , it will be changed to the test mode and all displays on the front of panel will be off.
- If any key on the front of panel is pressed within 15 seconds after the test mode, it will be operated as below sequence :
Manual operation1(FF) Manual operation2(OF-r) -> manual defrost of fresh food compartments(red) -> manual defrost of fresh and freezer compartments(fd) -> cancel(Display all off).
- If any key on the front of panel is not pressed within 15 seconds after the test mode, the test mode will be canceled and it will be returned to previous mode.

1) Manual operation function



- ① Energy Saver Key + Fridge Key are pressed simultaneously for 8 seconds, (displays are all off)

It will be changed to the test mode (manual operation) by pressing any key

- 1-1) If any key is pressed once in test mode, blinks "FF" on the display and it indicates the refrigerator has entered the manual operation. At this moment, buzzer beeps as an alarm.
- 1-2) If any key is pressed once at the manual operation1 status, OF-r will be displayed.
FF and OF-r means manual operation 1 and 2 separately. These 2 functions operate with same RPM of COMP.
- 1-3) If manual operation is selected, compressor will run at once without 7 minutes delay in any mode.
If the refrigerator is on the defrost cycle at the moment, defrost will be finished and manual operation will begin.
(Be careful if manual operation get started at the moment of compressor off, over load could be occurred)

Compulsion working 1 : 3600RPM



Compulsion working : 3600RPM



- 1-4) If manual operation works, compressor & f-fan operate continuously for 24 hours and fresh food compartment will be controlled by the setting temperature.
- 1-5) When the manual operation runs, setting temperature will be selected automatically as below: freezer compartment -8°F(-22°C), fresh food compartment 34°F(1°C).
- 1-6) During manual operation, Freezer Key & Power Cool function will not be work.
If a function is selected, the power function icon of the selected function will be off automatically after 10 seconds.
- 1-7) Manual operation can be canceled by removing power from the unit, then resupplying power.
- 1-8) Alarm(0.25 sec ON/ 0.75 sec OFF) will beep continuously until manual operation is completed and there is no function to make the sound stop.

2) Forced Defrost



- 2-1) When you press any key one more time at Fridge off Forced Operation [OF r], rd lights up on the Display Panel. At this time, the Forcd Operation stops immediately and R-Defrost will be performed at the same time.
- 2-2) When you press any key one more time at Forced R-Defrost [rd], Fd lights up on the Display Panel. At this time, FR-Defrost will be performed at the same time.
- 2-3) At this time, it will send out "Beep" sound for 2 seconds and then it will perform Forced F/R Defrost while sending out "0.5 sec On and 0.5 sec Off" sound.


3) Test cancel mode

- 3-1) During the simultaneous defrosting of fresh food and freezer compartments, if the display panel change to the test mode and test button is pressed one more time, defrosting of fresh food and freezer compartments will be canceled and the unit will return to the normal operation.
Or, all test functions will be canceled by turning main power ON and OFF.

4-1-2. Display function of Communication error

1) Display function when Panel MAIN MICOM communication has error

- 1-1) If there is no answer for 10 seconds after the panel micom received the requirement of communication, "Pc - Er" display on the panel PCB will be ON/OFF alternately until the communication error is canceled.
(0.5 sec ALL ON, 0.5 sec ALL OFF alternately)



- 1-2) "Pc - Er" display on the Pantry Room Display will be ON/OFF alternately until the communication error is canceled. (0.5 sec ALL ON, 1.5 sec ALL OFF alternately)

2) Display function when Panel MAIN MICOM OPTION has error


- 2-1) "OP - Er" code is repeatedly ON/OFF until Option error settles down.

TROUBLESHOOTING

4-1-3. Self-diagnostic function


1) Self-diagnostic function in the Initial power ON

- 1-1) Micom operates self-diagnostic function to check the temperature sensor condition within 1 second when the refrigerator turned On initially.
 - 1-2) If bad sensor is detected by the self-diagnostic function, the applicable display LED will blink for 0.5 sec. At this moment, there is no beep sound.(Refer to self-diagnostic CHECK LIST)
 - 1-3) Self-diagnostic button is recognized only when the error is displayed by the bad sensor. Display does not operate normally but temperature control will be controlled by the emergency operation.
 - 1-4) When the error is detected by self-diagnosis, the error can be canceled automatically if all troubled sensors are corrected or Self-diagnostic function key (Energy Saver Key + Alarm) are pressed simultaneously for 8 seconds.
- (Return to normal display mode)



- ① If Energy Saver Key + Alarm are pressed simultaneously for 8 seconds, the error mode by self-diagnosis will be canceled.

2) Self-diagnostic function during normal operation



- ② If Energy Saver Key + Alarm are pressed simultaneously for 8 seconds, the error mode by self-diagnosis will be canceled.

- 2-1) If Energy Saver Key + Alarm are pressed simultaneously for 6 seconds during normal operation, the temperature setting display will operate for 2 seconds (ON/OFF 0.5sec each). If Energy Saver Key + Alarm are pressed simultaneously for 8 seconds (including above 2 seconds), self-diagnostic function will be selected.
- 2-2) At this moment, self-diagnostic function will be returned with buzzer sound 'ding-dong'. If there is an error, display of error will be operated for 30 seconds and then return to normal condition whether problem is corrected or not. (Refer to self-diagnosis CHECK LIST)
- 2-3) Input by button is not accepted during self-diagnostic function.


※ R Self-diagnostics check list

LED		Item	Trouble contents	Diagnostic method
F	R			
88	88	FZ-Sensor Error	Display error : separation of sensor housing part, contact error, disconnection, short circuit, Display error of detecting temperature of sensor : more than 149°F(+65°C) or less than -58°F(-50°C)	When measuring the voltage between the Main PCB CN30-"4" ↔ CN76-"1", it should read between 4.5V~1.0V.
88		FF-Sensor Error		When measuring the voltage between the Main PCB CN30-"5" ↔ CN76-"1", it should read between 4.5V~1.0V.
88		FZ-DEF-Sensor Error		The voltage of MAIN PCB CN30- "5"↔ N76-"1": shall be between 4.5V~1.0V
88		FF-DEF-Sensor Error		When measuring the voltage between the Main PCB CN30-"8" ↔ CN76-"1", it should read between 4.5V~1.0V.
88		Ambient-Sensor Error		The voltage of MAIN PCB CN78- "8"↔ CN78-"12": shall be between 4.5V~1.0V
88		PANTRY-Sensor Error		The voltage of MAIN PCB CN78- "9"↔ CN76-"1": shall be between 4.5V~1.0V
88		Ice Maker(F) Sensor Error	Display error : separation of sensor housing part, contact error, disconnection, short circuit Display error of detecting temperature of sensor: more than 149°F(+65°C) or less than -58°F(-50°C)	The Voltage of MAIN PCB CN90 #8(-)→#9: Shall be between 4.5v ~ 1.0v
88		Humidity-Sensor Error	Separation of sensor housing part, contact error, disconnection, short circuit	When measuring the voltage between the Main PCB CN30-"3" ↔ CN76-"1", it should read between 4.5V~1.0V.
88		Ice Maker(FF) Sensor Error	Display error : separation of sensor housing part, contact error, disconnection, short circuit.	The voltage of MAIN PCB CN90- "1"↔ CN90-"7": shall be between 4.5V~1.0V
88		Ice Room Sensor Error	Display error of detecting temperature of sensor : more than 149°F(+65°C) or less than -58°F(-50°C)	When measuring the voltage between the Main PCB CN78-"10" ↔ CN78-"12", it should read between 4.5V~1.0V.
88		FZ-FAN Error	Display error during operation of applicable fan motor : Feed back signal line contact error, motor wire separation, motor error	The voltage of MAIN PCB CN76- "3"(Yellow) ↔ CN76-"1"(Gray): shall be between 7V~12V
88		FF-FAN Error	Display error during operation of applicable fan motor : Feed back signal line contact error, motor wire separation, motor error	The voltage of MAIN PCB CN76- "4"(Orange) ↔ CN76-"1"(Gray): shall be between 7V~12V
88		C-FAN Error	Display error during operation of applicable fan motor : Feed back signal line contact error, motor wire separation, motor error	The voltage of MAIN PCB CN76- "5"(Sky-blue) ↔ CN76-"1"(Gray): shall be between 7V~12V
88		FZ-DEF Error	Separation of freezer compartment defrost heater housing part, contact error, disconnection, short circuit or temperature fuse error. Display error : the defrosting does not finish though freezer compartment defrost is heating continuously for more than 80 minutes.	After separating MAIN PCB CN70 wire from PCB, resistance value between CN70 Brown ↔ CN70 Gray shall be 63(230) ohm ± 7%.(Resistance value is varied by input power) 0 ohm : heater short, ∞ ohm : wire/bimetal open (Must power off)
88		FF-DEF Error	Separation of fresh food compartment defrost heater housing part, contact error, disconnection, short circuit or temperature fuse error. Display error : the defrosting does not finish though fresh food compartment defrost is heating continuously for more than 80 minutes.	After separating MAIN PCB CN70 wire from PCB, resistance value between CN70 White ↔ CN70 Gray shall be 120(440) ohm± 7%.(Resistance value is varied by input power) 0 ohm : heater short, ∞ ohm : wire/bimetal open (Must power off)


TROUBLESHOOTING

※ R Self-diagnostics check list



LED		Item	Trouble contents	Diagnostic method
F	R			
28	88	Ice Maker(FZ) Function Error	When the Freezer Ice Maker error occurs more than 3 times, the error will be displayed.	After replacing the Ice Maker, check if it operates normal.
29		"Flex Zone-Damper-Heater Error"	Display error when open error is detected by damper heater : separation of Damper Heater housing part, contact error, disconnection, short circuit.	After separating MAIN PCB CN77 wire from PCB, resistance value between Black ↔ Brown wire shall be 135 ohm ± 7%. 0 ohm : heater short, ∞ Ohm : wire / bimetal Open.
33		FZ-Ice Pipe Heater Error	The error occurs when there is a wire connector slip-out of the Water Supply Pipe Heater, a contact error or a breakage in the wiring.	When measuring the resistance of the Main PCB CN79 Yellow-Pink wires, it should be within 102Ω ± 7%. 0Ω : heater short, ∞ Ω : Check for Wire Open or Connector Slip-out
39		Ice Maker(FF) Function Error	Display error when open error is detected by Heater : separation of Ice Pipe Heater housing part, contact error, disconnection, short circuit.	After changing the Ice Maker(R), plug the refrigerator power code again, and check the operation.
40		Ice Room-FAN Error	Display error during operation of applicable fan motor : Feed back signal line contact error motor wire separation motor error.	When measuring the voltage between the Main PCB CN76-"5" ↔ CN76-"I", it should read between 7.0V~12V.
43		Panel ↔ Main Communication Error	Display pc - Er in the panel with alarm : MICOM MAIN ↔ PANEL communication error.	Actually, If there is not a problem, it is desirable to replace Main and Panel PCB With the oscilloscope after a cable problem confirming.
63		FF Ice Duct Heater Error	The Error will be displayed when the Ice Duct Heater is detected as being open due to the followings. - Ice Maker Duct Heater Connector Slip-Out, Contact Defect or Wire-Breakage	The resistance between CN79 ORG and CN51 BRN on the Main PCB shall be within 135Ω ± 7%. And, when the resistance reads 0Ω or ∞ Ω, check the followings. 0Ω : Heater Short ∞ Ω : Wire-Breakage or Wire Slip-Out
81		Comp starting Failure Error	When the Compressor fails starting	Check if there is a short between compressor terminals. Check IPM Voltage [Under 13.5V]
82		IPM Fanlt Error	When there is a IPM Fault error	Check if there is a short between IPM Pins [#1~33] Check the Compressor and the Cycle
83		Comp Abnormal current Detection Error	When ther is abnormal crrunt detected at the Compressor	Check the Compressor connections Check the voltage of Resistance of R308 [0.090hm] Check the Compressor and the Cycle
84		Motor Locked Over RPM Error	When there is a Compressor restriction error	Check the voltage of Resistance of R308 [Short/Open] Check the voltage of both of C103 terminals [Unstable Voltage] Check the Compressor and the Cycle
85		Comp under voltage Error	When there is a low voltage error	Check the voltage of Resistance of R513 [Short/Open]
86		Comp over voltage Error	When there is a over voltage error	Check the voltage of Resistance of R501, R505, R509 [Short/Open]



4-1-4. Display function of Load condition



- ① If Energy Saver Key + Alarm are pressed simultaneously for 6 seconds, ALL ON/OFF will blink with 0.5 interval for 2 seconds.
 - ② If take the finger off from above keys and press Fridge, load condition mode will be started.
- 1) If Power Energy Saver Key + Alarm are pressed simultaneously for 6 seconds during normal operation, the temperature setting display of fresh food and freezer compartments will blink ALL ON/OFF with 0.5 for 2 seconds.
 - 2) At this moment, If Fridge Key after Energy Saver Key + Alarm is pressed, load condition display mode will be returned with alarm. At LED all on state, only load condition display will blink ON/OFF with 0.5 seconds interval.
 - 3) Load condition display mode shows the load that micom signal is outputting. However, It means that micom signal is outputting, it does not mean whether load is operating or not. That is to say that though load operation is displayed, load could not be operated by actual load error or PCB relay error etc. (This function would be applied at A/S.)
 - 4) Load condition display function will maintain for 30 seconds and then normal condition will be returned automatically.
 - 5) Load condition display is as below.




TROUBLESHOOTING

※ R Load mode Check list

Display LED	Display contents	Operation contents
R-1-①	R-FAN High	When FF compartment FAN operates with high speed, applicable LED ON
R-1-②	R-FAN Low	When FF compartment FAN operates with low speed, applicable LED ON
R-1-③	R-DEF Heater	When FF compartment defrost heater operates, LED ON
R-1-④	Start Mode	When refrigerator is plugged initially, LED ON
R-1-⑤	Overload condition	When ambient temperature is more than 93°F(34°C), LED ON
R-1-⑥	Low temperature condition	When ambient temperature is less than 72°F(22°C), LED ON
R-1-⑤,⑥ (ALL LED Off)	Normal Condition	When ambient temperature is between 73°F(23°C) and 91°F(33°C)
R1-⑨	Exhibition Mode	LED ON at the display mode.
F-1-①	COMP.	When COMP operates, applicable LED ON.
F-1-②	F-FAN High	When FZ compartment FAN operates with high speed, applicable LED ON.
F-1-③	F-FAN Low	When FZ compartment FAN operates with low speed, applicable LED ON.
F-1-④	F-DEF Heater	When FZ compartment defrost heater operates, LED ON
F-1-⑤	C-FAN High	When compressor FAN operates with high speed, applicable LED ON.
F-1-⑥	C-FAN Low	When compressor FAN operates with low speed, applicable LED ON.
F-10-①	Ice Room-FAN High	When Ice Room-FAN operates with high speed, applicable LED ON.
F-10-②	Ice Room-FAN Low	When Ice Room-FAN operates with low speed, applicable LED ON.
F-10-③	French Heater	When French heater operates, applicable LED ON
R-10-①	Pantry Room Damper Open	When damper open, applicable LED ON
R-10-②	Ice maker full	When the Ice Maker's Bucket is full, applicable LED ON in FF-room
R-10-③	Ice maker full	When the Ice Maker's Bucket is full, applicable LED ON in RZ-room
R-10-④	More Heater	Add to Assy Water Pipe Heater in Fre-room

4-1-5. Exhibition mode setting function




- ① If Energy Saver Key + Freezer Key are pressed for 5 seconds, Exhibition mode will be started.
- 1) If Energy Saver Key + Freezer are pressed simultaneously for 5 seconds during normal operation, Exhibition mode will be started with buzzer sound(ding-dong).
- 2) If above Energy Saver Key + Freezer Key are pressed one more time, Exhibition mode will be canceled.
- 3) If Exhibition mode is selected, blinks "OF-OF" on the temperature setting display of . The panel and it indicates the refrigerator has entered the Cooling Off mode.
- 4) During Exhibition mode, if fresh food and freezer compartments sensors are higher than 149°F(65°C). Exhibition will be canceled automatically and freezing operation will be returned.
(There is no buzzer sound when the Exhibition mode is canceled by the temperature.)
- 5) Operation contents of Exhibition Mode
 - Display, Fan motor and etc operate normally, not to operate compressor only.
 - Defrost is not operated. (including french heater)
 - Display function of the initial real temperature is finished.
 - Under the condition of Exhibition mode, Exhibition mode will be operated when Power On after Power OFF.

4-1-6. Option setting function


- If Freezer Key+ Alarm are pressed simultaneously for 12 seconds during normal operation, fresh food and freezer compartments temperature display will be changed to option setting mode.

KEY operation method for changing to option mode



- ① If Freezer Key+ Alarm are pressed simultaneously for 12 seconds, option setting mode will be started.

KEY control method after converting to option mode




R Key control in option mode

Energy Saver Key	Code Down key
Freezer Key	Code Up key
Alarm	Reference Value down key
Fridge key	Reference Value Up key

- If the display changes to option setting mode, all displays will be off except freezer and fridge compartments temperature display as below.
(Fresh food and freezer compartments case will be explained only because all options are operated with the same method according to the option table.)

TROUBLESHOOTING




- 1) For example, if you want to change freezer compartment standard temperature to -4°F (-2°C) by operating option, do as below. This function is for changing the standard temperature.
In -2°F (-19°C) of current temperature of freezer compartment, if you make the temperature lower to -4°F (-2°C) by the option, the standard temperature would be controlled -6°F (-21°C).
Therefore, if you change the setting of temperature option to -2°F (-19°C) on the panel, the appliance will be operated with -6°F (-21°C). It means that standard temperature is controlled -4°F (-2°C) less than setting temperature in the display.



NOTE

Basically, all the data in option has cleared from the factory.
Therefore, almost all setting value are "0".
But, some setting values could be changed for the purpose of improving performance.
You need to check the product manual and/or specification.

- 2) After changing to the option mode, fresh food compartment "0", freezer compartment "0" will be displayed.
(Basically fresh food compartment "0", freezer "0" would be set at shipping process, but setting value could be changed for the purpose of improving product at mass producing process.)
- If fresh food compartment "0" shows only, temperature reference value of freezer compartment will be set and current freezer compartment temperature code will be displayed on the freezer temperature display.
- 3) If freezer compartment "4" is set as below freezer compartment code after fresh food compartment "0" is set, standard temperature of freezer compartment will be lower than -4°F (-2.0°C).
(Refer to the picture "changing the freezer compartment temperature")



: If you wait for 20 seconds after completing the setting, MICOM will save the setting value to the EEPROM and normal display will be returned and the option setting mode will be canceled.

- 4) Option changing method as above is the same as all RFG29** model.
- 5) By the same method as above, it is possible to control the fresh food compartment temperature, water supply, ice-maker harvest temperature/time, defrost return time, hysteresis by temperature, notch gap by temperature etc.
- 6) Option function is set in the EEPROM at shipping process in the factory.
You would better not to change the option of your own.
Completing the setting is that option function return to normal display after 20 seconds.
Do not turn off the appliance before returning to the normal display mode.



NOTE


Option setting function exists in the other items.
We will skip the explanation of the other functions by the option because it is associated with refrigerator control function and is not needed at SERVICE.
(Please do not set the other options except above SERVICE Manual.)

4-1-7. Option TABLE

1) Temperature changing table of freezer compartment

Set item	Freezer Temp Shift
MODEL	RF263TEAE**, RF263BEAE**
Reference Value	Fridge Room 7-SEG
Value	0

Setting value	
FZ compartment Code	Temp. compensation
0	0°F(0.0°C)
1	-1°F(-0.5°C)
2	-2°F(-1.0°C)
3	-3°F(-1.5°C)
4	-4°F(-2.0°C)
5	-5°F(-2.5°C)
6	-6°F(-3.0°C)
7	-7°F(-3.5°C)
8	+1°F(+0.5°C)
9	+2°F(+1.0°C)
10	+3°F(+1.5°C)
11	+4°F(+2.0°C)
12	+5°F(+2.5°C)
13	+6°F(+3.0°C)
14	+7°F(+3.5°C)
15	+8°F(+4.0°C)




ex) If you want to change the freezer standard temperature to -4°F(-2°C)

2) Temperature changing table of fresh food compartment

Set item	Freezer Temp Shift
MODEL	RF263TEAE**, RF263BEAE**
Reference Value	Fridge Room 7-SEG
Value	1

Setting value	
FZ compartment Code	Temp. compensation
0	0°F(0.0°C)
1	-1°F(-0.5°C)
2	-2°F(-1.0°C)
3	-3°F(-1.5°C)
4	-4°F(-2.0°C)
5	-5°F(-2.5°C)
6	-6°F(-3.0°C)
7	-7°F(-3.5°C)
8	+1°F(+0.5°C)
9	+2°F(+1.0°C)
10	+3°F(+1.5°C)
11	+4°F(+2.0°C)
12	+5°F(+2.5°C)
13	+6°F(+3.0°C)
14	+7°F(+3.5°C)
15	+8°F(+4.0°C)

ex) If you want to change the freezer compartment standard temperature to 4°F(2°C)




TROUBLESHOOTING

3) Temperature changing table of ICE ROOM compartment .

Set item	ICE ROOM Temp shift
MODEL	RF263TEAE**, RF263BEAE**
Reference Value	Fridge Room 7-SEG
Value	20

Setting value	
FZ compartment Code	Temp. compensation
0	8.6°F(-13°C)
1	6.8°F(-14°C)
2	5°F(-15°C)
3	3.2°F(-16°C)
4	1.4°F(-17°C)
5	-0.4°F(-18°C)
6	-2.2°F(-19°C)
7	10.4°F(-12°C)

ex) If you want to change the freezer compartment standard temperature to 10.4°F(-12°C).




4) Temperature changing table of Pantry Room compartment

- Could change the temperature of Pantry Room in fresh food compartment.

Set item	PANTRY ROOM Temp shift
MODEL	RF263TEAE**, RF263BEAE**
Reference Value	Fridge Room 7-SEG
Value	33

Setting value	
FZ compartment Code	Temp. compensation
0	0°F(0.0°C)
1	-1°F(-0.5°C)
2	-2°F(-1.0°C)
3	-3°F(-1.5°C)
4	-4°F(-2.0°C)
5	-5°F(-2.5°C)
6	-6°F(-3.0°C)
7	-7°F(-3.5°C)
8	+1°F(+0.5°C)
9	+2°F(+1.0°C)
10	+3°F(+1.5°C)
11	+4°F(+2.0°C)
12	+5°F(+2.5°C)
13	+6°F(+3.0°C)
14	+7°F(+3.5°C)
15	+8°F(+4.0°C)

ex) If you want to change the freezer compartment standard temperature to 4°F(2°C).



4-2) Diagnostic method according to the trouble symptom(Flow Chart)

DATA1.Temperature table

Resistance value and MICOM port voltage of sensor according to the temperature

SENSOR CHIP : based on PX41C, PX41C, 502AT/ 103**(ICE MAKER SENSOR(MOLD)/FULL UP, 20Kohm
(Actual measurement = value of the table below X 2)

°C	°F	Voltage	Resistance	°C	°F	Voltage	Resistance	°C	°F	Voltage	Resistance
-50	-58	4.694	153319	-5	23	3.107	16419	40	104	1.153	2997
-49	-56.2	4.677	144794	-4	24.8	3.057	15731	41	105.8	1.124	2899
-48	-54.4	4.659	136798	-3	26.6	3.006	15076	42	107.6	1.095	2805
-47	-52.6	4.641	129294	-2	28.4	2.955	14452	43	109.4	1.068	2714
-46	-50.8	4.622	122248	-1	30.2	2.904	13857	44	111.2	1.040	2627
-45	-49	4.602	115631	0	32	2.853	13290	45	113	1.014	2543
-44	-47.2	4.581	109413	1	33.8	2.802	12749	46	114.8	0.988	2462
-43	-45.4	4.560	103569	2	35.6	2.751	12233	47	116.6	0.963	2384
-42	-43.6	4.537	98073	3	37.4	2.700	11741	48	118.4	0.938	2309
-41	-41.8	4.514	92903	4	39.2	2.649	11271	49	120.2	0.914	2237
-40	-40	4.490	88037	5	41	2.599	10823	50	122	0.891	2167
-39	-38.2	4.465	83456	6	42.8	2.548	10395	51	123.8	0.868	2100
-38	-36.4	4.439	79142	7	44.6	2.498	9986	52	125.6	0.846	2036
-37	-34.6	4.412	75077	8	46.4	2.449	9596	53	127.4	0.824	1973
-36	-32.8	4.385	71246	9	48.2	2.399	9223	54	129.2	0.803	1913
-35	-31	4.356	67634	10	50	2.350	8867	55	131	0.783	1855
-34	-29.2	4.326	64227	11	51.8	2.301	8526	56	132.8	0.762	1799
-33	-27.4	4.296	61012	12	53.6	2.253	8200	57	134.6	0.743	1745
-32	-25.6	4.264	57977	13	55.4	2.205	7888	58	136.4	0.724	1693
-31	-23.8	4.232	55112	14	57.2	2.158	7590	59	138.2	0.706	1642
-30	-22	4.199	52406	15	59	2.111	7305	60	140	0.688	1594
-29	-20.2	4.165	49848	16	60.8	2.064	7032	61	141.8	0.670	1547
-28	-18.4	4.129	47431	17	62.6	2.019	6771	62	143.6	0.653	1502
-27	-16.6	4.093	45146	18	64.4	1.974	6521	63	145.4	0.636	1458
-26	-14.8	4.056	42984	19	66.2	1.929	6281	64	147.2	0.620	1416
-25	-13	4.018	40938	20	68	1.885	6052	65	149	0.604	1375
-24	-11.2	3.980	39002	21	69.8	1.842	5832	66	150.8	0.589	1335
-23	-9.4	3.940	37169	22	71.6	1.799	5621	67	152.6	0.574	1297
-22	-7.6	3.899	35433	23	73.4	1.757	5419	68	154.4	0.560	1260
-21	-5.8	3.858	33788	24	75.2	1.716	5225	69	156.2	0.546	1225
-20	-4	3.816	32230	25	77	1.675	5039	70	158	0.532	1190
-19	-2.2	3.773	30752	26	78.8	1.636	4861	71	159.8	0.519	1157
-18	-0.4	3.729	29350	27	80.6	1.596	4690	72	161.6	0.506	1125
-17	1.4	3.685	28021	28	82.4	1.558	4526	73	163.4	0.493	1093
-16	3.2	3.640	26760	29	84.2	1.520	4369	74	165.2	0.481	1063
-15	5	3.594	25562	30	86	1.483	4218	75	167	0.469	1034
-14	6.8	3.548	24425	31	87.8	1.447	4072	76	168.8	0.457	1006
-13	8.6	3.501	23345	32	89.6	1.412	3933	77	170.6	0.446	978
-12	10.4	3.453	22320	33	91.4	1.377	3799	78	172.4	0.435	952
-11	12.2	3.405	21345	34	93.2	1.343	3670	79	174.2	0.424	926
-10	14	3.356	20418	35	95	1.309	3547	80	176	0.414	902
-9	15.8	3.307	19537	36	96.8	1.277	3428	81	177.8	0.404	877
-8	17.6	3.258	18698	37	98.6	1.253	3344	82	179.6	0.394	854
-7	19.4	3.208	17901	38	100.4	1.213	3204	83	181.4	0.384	832
-6	21.2	3.158	17142	39	102.2	1.183	3098	84	183.2	0.375	810

TROUBLESHOOTING

4-2) Diagnostic method according to the trouble symptom(Flow Chart)

DATA2. Humidity Sensor table

- Voltage output table @23°..., 5Vdc --- HTG3515CH/HTG3535CH

$RH(\text{Temperature compensate}) = RH(\text{Relative Humidity}) + (\text{Temp}(^{\circ}\text{C}) - 23^{\circ}\text{C}) \times 0.05$

°C	°F	Voltage	Resistance	°C	°F	Voltage	Resistance	°C	°F	Voltage	Resistance
0	909	186	744	46	2246	460	1839	92	3452	706	2827
1	943	193	772	47	2272	465	1861	93	3478	712	2848
2	977	200	800	48	2298	470	1882	94	3504	717	2870
3	1010	207	827	49	2324	475	1903	95	3530	722	2891
4	1043	213	854	50	2350	481	1925	96	3566	730	2920
5	1076	220	881	51	2376	486	1946	97	3595	735	2944
6	1109	227	908	52	2402	491	1967	98	3624	741	2968
7	1141	233	935	53	2428	497	1989	99	3653	747	2992
8	1173	240	961	54	2454	502	2010	100	3683	754	3016
9	1205	247	987	55	2480	507	2031				
10	1235	253	1011	56	2505	513	2052				
11	1266	259	1037	57	2530	518	2072				
12	1297	265	1062	58	2555	523	2093				
13	1328	272	1088	59	2580	528	2113				
14	1359	278	1113	60	2605	533	2133				
15	1390	284	1138	61	2630	538	2154				
16	1420	291	1163	62	2655	543	2174				
17	1450	297	1188	63	2680	548	2195				
18	1480	303	1212	64	2705	553	2215				
19	1510	309	1237	65	2730	559	2236				
20	1540	315	1261	66	2756	564	2257				
21	1569	321	1285	67	2782	569	2278				
22	1598	327	1309	68	2808	575	2300				
23	1627	333	1333	69	2834	580	2321				
24	1656	339	1356	70	2860	585	2342				
25	1685	345	1380	71	2886	590	2364				
26	1713	350	1403	72	2912	596	2385				
27	1741	356	1426	73	2938	601	2406				
28	1769	362	1449	74	2964	606	2428				
29	1797	368	1472	75	2990	612	2449				
30	1825	373	1495	76	3017	617	2471				
31	1852	379	1517	77	3044	623	2493				
32	1879	384	1539	78	3071	628	2515				
33	1906	390	1561	79	3098	634	2537				
34	1933	395	1583	80	3125	639	2559				
35	1960	401	1605	81	3152	645	2581				
36	1986	406	1627	82	3179	650	2604				
37	2012	412	1648	83	3206	656	2626				
38	2038	417	1669	84	3233	661	2648				
39	2064	422	1690	85	3260	667	2670				
40	2090	428	1712	86	3288	673	2693				
41	2116	433	1733	87	3316	678	2716				
42	2142	438	1754	88	3344	684	2739				
43	2168	444	1776	89	3372	690	2762				
44	2194	449	1797	90	3400	696	2785				
45	2220	454	1818	91	3426	701	2806				

TROUBLESHOOTING

4-2-1. If the trouble is detected by self-diagnosis

- The error of sensor will be displayed on the front of display.
when the error of sensor is detected at initial power ON, the appliance will not operated and display of abnormal sensor part will blink.
- The appliance will not stop operating when the error of sensor is detected during operation of the appliance.
But normal freezing might be not operated if the appliance is operated by the emergency operation mode. You would better to check the appliance according to the self-diagnosis of the manual.

1) If ICE Maker(R) Sensor has troubled

ERROR Code




DATA1.
Temperature table

** Measuring point of resistance value according to Sensor **
ICE MAKER: CN90 "1" ↔ "7" measuring resistance value ** 0Ω: Short trouble / ∞: Open trouble

Refer to circuit diagram in the manual

Sensor MICOM/Connector number	
ICE Maker	Connector CN90-"1"(Brown) and J23 JUMMPER PCB typical Ground
Voltage measured between 4.6V ~ 0.6V.	

Measuring voltage of IC01 MICOM #71, CN90 - "1" (Brown) and J23 JUMMPER from PCB typical Ground part are similar.
→ Check the measure on the voltage of Resistance, R914 DUE to the SMD MICOM




- ☞ Checking method of ICE Maker Sensor resistance
CN90 "1"(Brown) ↔ "7"(Gray)
- Compare the temperature table after the measure.



- ☞ Checking method of ICE Maker Sensor resistance
- Measure the voltage of Resistance R914(IC01 MICOM #71) on PCB or CN90 "1"(Brown) ↔ J23 JUMMPER
 - Compare the temperature table after the measure.
- Measuring voltage of CN90-"1"(Brown) ↔ J23 JUMMPER are as below.




PCB Typical Ground
J23 JUMMPER




2) ICE Maker(FZ) Sensor has troubled

ERROR Code



- This refrigerator has Dual Ice Maker, so controlled two Ice Makers.



☞ Checking Method of ICE MAKER(F) Sensor resistance CN90 "9"(Red) ↔ 8"(White)
- Compare the temperature table after the measure.



☞ Checking method of ICE Maker Sensor
- Measure the voltage of Resistance R904(IC01 MICOM #75) or CN90-"9"(Red) ↔ J23 JUMMPER.
- Compare the temperature table after the measure. Measuring voltage of CN90-"9"(Red) ↔ J23 JUMMPER.



typical PCB Ground J23 JUMMPER



TROUBLESHOOTING

3) If R Sensor has trouble

ERROR Code



DATA1.


Temperature table

** Measuring point of resistance value according to Sensor **
R : CN30 - "6" ↔ CN76-"1" measuring resistance value
** 0Ω : Short trouble / Ω ∞ : Open trouble

Refer to circuit diagram in the manual

Sensor MICOM/Connector number	
R	Connector CN30 - "6"(White) to J23 JUMMPER PCB typical Ground Voltage measured between 4.6V ~ 0.6V.

Measuring voltage IC01 MICOM #84, CN30 - "6"(White) and J23 JUMMPER from PCB typical Ground part are similar.
→ Check the measure on the voltage of Resistance, R311 due to the SMD MICOM




☞ Checking method of R Sensor resistance
CN30 - "6"(White) ↔ CN76-"1"(Gray) Compare the temperature table after measurement.



☞ Checking method of R Sensor resistance
- Measure the voltage of Resistance R311(IC01 MICOM #84) on PCB or CN30 - "6"(White) ↔ J23 JUMMPER
- Compare the temperature table after measurement.
Measuring voltage of CN30 - "6"(White) ↔ J23 JUMMPER are as below.




PCB Typical Ground
J23 JUMMPER




4) If R DEF Sensor has trouble

ERROR Code



DATA1. Temperature table	
** Measuring point of resistance value according to Sensor ** R-DEF : CN30-"8" ↔ CN76-"1" measuring resistance value ** 0Ω : Short trouble Ω ∞ : Open trouble	
Refer to circuit diagram in the manual	
Sensor MICOM/Connector Number	
R DEF	Connector CN30-"8"(Sky-blue) and J23 JUMMPER PCB typical Ground
Voltage measured between 4.6V ~ 0.6V.	
Measuring voltage of IC01 MICOM #86 CN30-"8"(Sky-blue) and J23 JUMMPER from PCB typical Ground part are similar. → Check the measure on the voltage of Resistance R313 due to the SMD MICOM	



- ☞ Checking method of R Sensor resistance CN30-"8"(Sky-blue) ↔ CN76-"1"(Gray)
- Compare the temperature table after measurement.



- ☞ Checking method of R DEF Sensor resistance

- Measure the voltage of Resistance R313(IC01 MICOM #86) on PCB or CN30-"8"(Sky-blue) ↔ J23 JUMMPER
 - Compare the temperature table after measurement.
- Measuring voltage of CN30-"8"(Sky-blue) ↔ J23 JUMMPER are as below.




PCB Typical Ground
J23 JUMMPER



TROUBLESHOOTING

5) If Ambient Sensor has trouble

ERROR Code




DATA1.
Temperature table

** Measuring point of resistance value according to Sensor **
 Ambient : CN78-"8" ↔ "12" measuring resistance value
 ** Placed in the right top table of upper hinge.
 ** 0Ω : Short trouble / ∞ : Open trouble

Refer to circuit diagram in the manual

Sensor MICOM/Connector number	
Ambient	Connector CN78-"8"(Yellow) to J23 JUMMPER PCB typical Ground
Voltage measured between 4.6V ~ 0.6V.	

Measuring voltage of IC01 MICOM #93
 CN78-"8"(Yellow) and J23 JUMMPER from
 PCB typical Ground part are similar.
 → Check the measure on the voltage of Resistance,
 R315 due to the SMD MICOM



- ☞ Checking method of Ambient Sensor resistance
 CN78-"8"(Yellow) ↔ "12"(Yellow)
 - Compare the temperature table after measurement.



- ☞ Checking method of Ambient Sensor voltage
 - Measure the voltage of Resistance R315(IC01 MICOM #93) on PCB or CN78-"8"(Yellow) ↔ J23 JUMMPER
 - Compare the temperature table after measurement.
 Measuring voltage of CN78-"8"(Yellow) ↔ J23 JUMMPER are as below




PCB Typical Ground
J23 JUMMPER



6) If F Sensor has trouble

ERROR Code




DATA1.
Temperature table

** Measuring point of resistance value according to Sensor **
F : CN30-"4" ↔ CN76-"1" measuring resistance value
** 0Ω: Short trouble / ∞Ω: Open trouble

Refer to circuit diagram in the manual

Sensor MICOM/Connector number	
F	Connector CN30-"4"(Red) to J23 JUMMPER PCB typical Ground Voltage measured between 4.6V ~ 0.6V.

Measuring voltage of IC01 MICOM #82, CN30-"4"(Red) and J23 JUMMPER from PCB typical Ground part are similar.
→ Check the measure on the voltage of Resistance, R309 due to the SMD MICOM



☞ Checking method of F Sensor resistance CN30-"4"(Red) ↔ CN76-"1"(Gray)
- Compare the temperature table after measurement.



☞ Checking method of F Sensor voltage
- Measure the voltage of Resistance, R309(IC01 MICOM #82) on PCB or CN30-"4"(Red) ↔ J23 JUMMPER
- Compare the temperature table after measurement.
Measuring voltage of CN30-"4"(Red) ↔ J23 JUMMPER are as below.



PCB Typical Ground
J23 JUMMPER




TROUBLESHOOTING

7) If F DEF Sensor has trouble

ERROR Code



DATA1.	Temperature table
** Measuring point of resistance value according to Sensor ** F-DEF : CCN30-"5" ↔ CN76-"1" measuring resistance value ** 0Ω: Short trouble / ∞: Open trouble Refer to circuit diagram in the manual	
Sensor MICOM/Connector number	
F DEF	Connector CN30-"5"(Orange) to J23 JUMMPER PCB typical Ground Voltage measured between 4.6V ~ 0.6V.
Measuring voltage of IC01 MICOM #83, CN30-"5"(Orange) and J23 JUMMPER from PCB typical Ground part are similar. → Check the measure on the voltage of Resistance, R310 due to the SMD MICOM	



- ☞ Checking method of F DEF Sensor resistance
 CN30-"5"(Orange) ↔ CN76-"1"(Gray)
 - Compare the temperature table after measurement.



- ☞ Checking method of F DEF Sensor voltage
 - Measure the voltage of Resistance, R310(IC01 MICOM #83) on PCB or CN30-"5"(Orange) ↔ J23 JUMMPER
 - Compare the temperature table after measurement.
 Measuring voltage of CN30-"5"(Orange) ↔ J23 JUMMPER are as below




PCB Typical Ground
 J23 JUMMPER




8) If Ice Room Sensor has trouble

ERROR Code



DATA1. Temperature table	
** Measuring point of resistance value according to Sensor ** Ambient : CN78 "10" ↔ CN76 "1" Measure the voltage of Resistance value ** 0Ω : Short trouble / ∞ : Open trouble	
Refer to the circuit diagram in this manual	
Sensor MICOM/Connector number	
Ice Room	Connector CN78-"10"(Orange) and J23 JUMMPER from PCB Typical Ground Voltage measured between 4.6V ~ 0.6V.
Measuring voltage of IC01 MICOM #92, CN78-"10"(Orange) and J23 JUMMPER from PCB Typical Ground are similar. → Check the measure on the voltage of Resistance, R316 due to the SMD MICOM	




Checking Method of Ice Room Sensor voltage
CN78-"10"(Orange) ↔ CN76-"1" (Gray)
- Compare with the temperature table after measurement.



Checking Method of Ice Room Sensor Voltage
- Measure the voltage of Resistance, R316(IC01 MICOM #92) on PCB or CN78-"10"(Orange) ↔ J23 JUMMPER
- Compare with the temperature table after measurement.
Measured voltage of CN78-"10"(Orange) ↔ J23 JUMMPER are as below




PCB Typical Ground
J23 JUMMPER




TROUBLESHOOTING

9) If PANTRY Sensor has trouble

ERROR Code



DATA1. Temperature table	
** Measuring point of resistance value according to Sensor ** Flex : CN30 "9" ↔ CN76 "1" measuring resistance value ** 0Ω : Short trouble / ∞Ω : Open trouble	
Refer to circuit diagram in the manual	
Sensor MICOM/Connector number	
Pantry	Connector CN30-"9"(Yellow) to J23 JUMMPER PCB typical Ground Voltage measured between 4.6V ~ 0.6V.
Measuring voltage of IC01 MICOM #87, CN30-"9"(Yellow) and J23 JUMMPER from PCB typical Ground part are similar. → Check the measure on the voltage of Resistance, R314 due to the SMD MICOM	



☞ Checking method of PANTRY Sensor resistance
 CN30-"9"(Yellow) ↔ CN76-"1" (Gray)
 - Compare the temperature table after measurement.



☞ Checking method of PANTRY Sensor resistance CN30-"9"(Yellow) ↔ CN76-"1" (Gray)
 - Compare the temperature table after measurement.
 Measuring voltage of CN30-"9"(Yellow) ↔ J23 JUMMPER are as below



PCB Typical Ground
 J23 JUMMPER



10) If Humidity Sensor has trouble

ERROR Code



** Measuring point of resistance value according to Sensor"


Humidity : CN30 "1" ↔ "3"
Resistance value with opened : about 50 Ω
** 0 Ω : Short trouble / Ω ∞ : Open trouble

Refer to circuit diagram in the manual

Sensor MICOM/Connector number

Humidity	Connector CN30-"3"(brown) to J23 JUMMPER PCB typical Ground
Voltage measured between 3.5V ~ 1.0V	

Measuring voltage of IC01 MICOM #81,
CN30-"3"(Brown) and J23 JUMMPER from
PCB typical Ground part are similar.
→ Check the voltage of Resistance, R321



- ☞ Checking method of Humidity Sensor resistance
CN30-"3"(Brown) ↔ "1"(Gray)
- Compare the temperature table after the measure.



- ☞ Checking method of Humidity Sensor voltage.
- Measure the voltage of Resistance, R321(ICO1 MICOM #81) on PCB or CN30-"3"(Brown) ↔ J23 JUMMPER
- Compare the temperature table after the measure.
- Measuring voltage of CN30-"3"(Brown) ↔ J23 JUMMPER are below




PCB Typical Ground
J23 JUMMPER



TROUBLESHOOTING


11) PANTRY Room Damper Heater has trouble(OPTION)

ERROR Code



Measure the voltage of Resistance between ① - ② after CN77 connector open / 1350 ohm \pm 7%

MICOM #56 condition	Initial power On	Heater off	Working heater
	3.5V ~ 4.8V	3.5V ~ 4.8V	0V




☞ Checking method of Flex Zone Room Damper resistance CN77-"1"(Black) ↔ "2"(Brown)
 ** $\Omega \infty$: Open (wire disconnection, heater disconnection) trouble / 0Ω : Short trouble



4-2-2. If FAN does not operate

- The refrigerator of this model has BLDC FAN motor. BLDC motor is driven by DC 7~12V.
 - On the normal condition of COMP ON, it operates together with F-FAN motor.
- If door is opened and closed once at a high ambient temperature, it will be operated after 1 minute delay.
- Therefore, you are advised not to taken it for an error.
- If there is a trouble, you should select the self-diagnostic function to check the trouble before power off.



TROUBLESHOOTING

4-2-3. If ICE Room Fan does not operate

- This refrigerator has BLDC FAN motor. BLDC motor is driven by DC7~12V.
- When COMP ON, normally operates with F-FAN motor.
- If there is any trouble, you should select the self-diagnostic function to check the trouble before power off.

- When pressing the ICE TEST S/W for a certain period of time (over 1.5sec), the function is accomplished. After beginning of TEST mode, Ice maker heater turns on for initial 2 minutes, if the ice making temperature is below 0°C.
- If it exceeds 0°C, Ice maker heater turns on for initial 30 seconds.
- After Ice maker heater turns on for 30 seconds, it turns off and then Ice maker motor turns on.
- As the Ice maker motor turns on, TEST MODE COUNT operates. (6 minutes count)




Condition

- Ambient temperature : 32°C/75%
- Notch : 2°F/38°F(-19.0°C/3.3°C)
- Initial full of ice bucket capacity : 794 g, 58ea

Ice Room control temperature	
Ice ON	8.6°F(-13°C)
Ice OFF	26.6°F(-3°C)

Reference

CN76 "6" will generate the pulse signal when motor rotates. These signals will be input into MICOM. Unless signals are not input during motor operating, will be ON 10seconds after fan OFF. But if signals are not still taken, the above operation will be retried four times more. If signals are not taken continuously, the motor will be restarted after 10 minutes. This function is against the case that motor movement would be restrained by foreign matters like ice.



- ※ Predicted Cause
- ① FAN-MOTOR troubles itself
 - ② Bad wiring connections.
 - ③ Wrong Input of the fan motor rotation pulse

☞ Checking method of Ice Room FAN Motor Voltage with the voltage between Ice Room FAN ; CN76-"1"(Gry) shall be less than DC 7~12V.

- Ice Room FAN Motor Voltage shall be less than DC 7~12V.

1) Ice Room - FAN




PCB Typical Ground J23 JUMMPER



4-2-4. When ICE MAKER(FF) does not operate

1. Water will be automatically supplied to the Ice Maker depending on temperature & time conditions, and ice will be produced to dispense.
2. Power is applied to one end of the wires. So, make sure to refer to its Exploded View whenever doing the disassembly.
3. The operation of the Ice Maker shall be done after pressing the Ice Maker Test Button.
(Fridge Ice Maker) It is not possible to check when the power is off.
4. Since both of the PCB and the Ice Maker are located at the front and the back each other, make sure to have two people check them.
5. It may cause burn when the Ice Maker Heater heats up. So, please take an extra caution.
6. The Ice Maker has a counter-clockwise rotation function. So, its counter-clockwise rotation is normal.

Displays ERROR Code



TROUBLESHOOTING


4-2-5. When ICE MAKER(FZ) does not operate

1. Water will be automatically supplied to the Ice Maker depending on temperature & time conditions, and ice will be produced to dispense.
2. Power is applied to one end of the wires. So, make sure to refer to its Exploded View whenever doing the disassembly.
3. The operation of the Ice Maker shall be done after pressing the Ice Maker Test Button.
(Freezer Ice Maker) It is not possible to check when the power is off.
4. Since both of the PCB and the Ice Maker are located at the front and the back each other, make sure to have two people check them.

ERROR Code



Operation Condition while Motor is rotating Micom(IC01) Operation Status		
	Stand-by	On
Motor CW Rotation (#54)	0V	5V
Motor CCW Rotation (#53)	0V	5V
Its operation status changes as the Motor rotates CW or CCW.		




4-2-6. If defrost does not operate (F,R DEF Heater)

R DEF ERROR



F DEF ERROR



TROUBLESHOOTING

4-2-7. When Power is not applied

CAUTION

There are AC Input Voltage and over DC300V at the INVERTER PCB Power Circuit. So, be cautious when repairing the unit or measuring values.

Check at SMPS

How to Check Voltage CN102 – "3" (Grey) ↔ "1" (Gray) AC Voltage




How to Check DC Secondary Voltage Between Trans Pin #1 and Pin #6 → Same as both terminals of C121.
DC 13.2V ± 0.7V



How to Check DC Secondary Voltage REG3 Output ; Regulator 7805 Input → Same as both terminals of C118.
DC 5V ± 0.2V




When checking the MAIN PCB, refer to the Operation descriptions and the "Reference" section.



– Check the MAIN PCB connection
– Check the wire connection at the Door Hinge
– Check the connection of Door Panel PCB


4-2-8. When Compressor does not run (Inverter COMP.)




TROUBLESHOOTING

4-2-9. When alarm sounds continuously without stop(related with buzzer sound)

① If 'ding-dong'sound continuously



② If 'beep-beep' sounds continuously




③ If buzzer does not sound

Buzzer is installed on the panel PCB in this model.

If buzzer does not sound even though the button is pressed, manual operation is started and door is opened, it should separate panel PCB and check the breakage of buzzer and bad soldering.

It is very hard to repair the panel PCB because it consists of SMD assemblies.

It is recommended to replace PCB assembly when the failure associated with panel is occurred except the minor error such as switch pressing error, surface peeling off and so on.




TROUBLESHOOTING

4-2-10. When the Panel PCB does not operate normally


① When the entire or a certain section of the Panel PCB does not light up

- There is a MICOM embedded in the Panel PCB. So, take care when doing repairs. And, except the Solder Touch, replace the PCB.



② When the Panel PCB buttons do not work


※ When it keeps troubling after check with the above procedures
[Check after turning off the unit and turning it on again]



Since all Touch is used for the Panel PCB Switch, be sure to turn off the unit and turn it on again after doing a repair. [It is to adjust the sensitivity of the Touch Panel.]

4-2-11. If Pantry Panel PCB is not working normally

You should check the display after door opening because the display of this model operates only when the fresh food compartment door is opened.



② If Panel PCB Key is not selected

※ If it is not repaired with the above basic checking method


PCB Typical Ground J23 JUMMPER



The Voltage of KEY is Working every 2msec/4min

☞ Checking method of voltage Based on PCB typical Ground J23 JUMMPER

- 1) Key voltage ; CN51-"11"(Sky Blue)
a) Working: $2V \pm 0.5V$ b) Normal: 0V




TROUBLESHOOTING

4-2-12. When refrigerator ROOM Lamp does not light up

When controlling the refrigerator light with Regulator(12V) : LED LAMP

→ Applying to the F/R Room compartment (Option)

* If the Vegetable Lamp does not work properly, check the R compartment LED Lamp because it is connected with the R compartment LED Lamp in parallel. Refer to the circuit diagram to repair.



1) Measuring output voltage

- Measuring the voltage of PCB typical Ground J23 JUMMPER and IC76 voltage(CN78-"3"(Red)/R LED), IC77 voltage (CN78-"1"(Brown)/F LED)

R LED Lamp ON



R LED Lamp OF



Checking method of Door switch voltage.

- Measuring voltage of CN76-"12"(Purple) ↔ PCB typical Ground J23 JUMMPER



Close



Open

PCB Typical Ground J23 JUMMPER



4-2-13. If ICE Water is not supplied

1. Please shut the water supplying prior to repair.
2. Power is applied to the one end of wires. Be careful when disassembling not to get an electric shock.

2) Ice Water(R) Valve

PCB Typical Ground J23 JUMMPER



Checking method of voltage Based on PCB typical Ground J23 JUMMPER

- 1) Check the voltage of IC73-"4"(same voltage as IC01 "104")
- ICE Water valve waiting (about 0V)



Based on PCB typical Ground J23 JUMMPER


- 2) IC73-"13" voltage
- ICE Water valve Waiting (about $12V \pm 0.8V$)
- ICE Water valve operating (about $0.7V \pm 0.5V$)



- 3) Check the voltage of Water Valve operating (AC voltage)

=> For checking the Relay RY78 operating.

- CN70-"5"(Red) ↔ CN73_1-"1"(Purple)
- ICE Water valve waiting (about AC 0V)



TROUBLESHOOTING

2) Ice Water(F) Valve

Typical PCB Ground J23 JUMMPER



⇒ Checking method of voltage Based on PCB typical Ground J23 JUMMPER

1) Check the voltage of IC75 -"6"(same voltage as IC01 #116)

- ICE Water valve operating (about $5V \pm 0.5V$)



Based on PCB typical Ground J23 JUMMPER

2) IC75 -"11" voltage

- ICE Water valve Waiting (about $13V \pm 0.8V$)

- ICE Water valve operating (about $0.7V \pm 0.5V$)



3) Check the voltage of Frigde Ice Water(F) Valve operating(AC voltage)


⇒ For checking the Relay RY76

CN70-"5"(Red) ↔ CN72-"1"(Brown)


- ICE Water valve waiting (about AC 0V)



- ICE Water valve operating (about AC $115V \pm 20\%$)



4-2-14. If Cubed or Crushed Ice is not supplied




TROUBLESHOOTING

4-2-15. If Cover Ice Route Motor(Geared Motor) is not working normally

Caution

1. When replacing the Cover Ice Motor, pull out the plug to avoid an electric shock.
2. Be careful! When disassemble the Cover Ice Motor, spring can jumped out and may cause personal injury.
3. Motor will rotate continuously when the Motor Switch is not sensed.

☞ Checking Method of Cover Ice Route Motor Resistance
(Make sure to work after Power Off)
the voltage of Resistance is variable according to the input voltage.
CN70 -"5" (Red) ↔ CN73_1 -"3" (Blue)
** 0Ω: Short trouble / Ω ∞: Open trouble



Operating Condition of Dispenser Open/Close CN50 - Switch 1,2 Operating			
	Close	ing	Open
Ice Route Switch 1 CN50 - "9" (Purple)	0V	5V	0V
Ice Route Switch 2 CN50 - "10" (White)	0V	5V	0V

- ① Main PCB - Check the wire OPEN/SHORT between the Cover Ice Motor Rotation sensing switches.
- ② Check the Short of Cover Ice Motor Control Circuit SSR75 in the MAIN PCB.
- ③ Replace the MAIN PCB or the Dispenser Cover Motor.


4-2-16. When there is no power at Inverter PCB

Caution

There is Over AC 115V and DC 310V at the Inverter PCB Power Circuit. So, be cautious when repairing the unit or measuring values..



- To check the Inverter PCB, refer to the Operation and 'Refer' sections in this manual










TROUBLESHOOTING

4-2-17. LED blinking frequency depending on protecting functions

If Failure Condition is detected during compressor is operating, immediately stop Compressor operating and stand by 5 minutes. During this 5 minutes, RPM command signal is not available. It means, even if available RPM command signal is applied to the compressor, it does not work and keep standing by.


Blinking time is 1 second and dwell time is 2 seconds.

LED Blinking Frequency	Protecting Functions	Remarks
	Normal Operation	N/A
	Starting Failure	1. Short between COMP U,V, and W phase(CN301) 2. Short among IPM Pins(No. #1~33)
	SPM Fault	3. Drop the IPM operating Voltage under DC 13.5V 4. Other cases, cjeck the COMP, cycle, etc.
	Abnormal Current Detection	1. Open the COMP wire(CN301) 2. Bad condition of R 308(ex. Bad soldering) 3. Other cases, cjeck the COMP, cycle, etc.
	Motor Locked / Over RPM	1. Operating the locked rotor COMP with in 5 second. 2. Operating the COMP under 1000RPM more than 5secod. 3. Short the shunt resistor between leads. 4. Occur the huge change of input voltage in a moment 5. Other cases, check the COMP, cycle,etc.
	Under Voltage	1. Drop the input voltage under AC 53V 2. Short resistor R513(DC link resistor)
	Over Voltage	1. Increase the input voltage over AC 154V 2. Short resistor among R501, R505 and R509 (DC link resistor)


LED blinking frequency depending on protecting functions

If the same blinking, After 5 minutes, Follow the Remarks

SPM FREEWHEELING DIODE VOLTAGE VALUE



INVERTER PCB Circuit Diagram



5. PCB DIAGRAM


5-1) PCB Layout with part position 94

5-2) PCB Layout with part position (Inverter Board)..... 95

5-3) Connector Layout with part position (Main Board) 96


5-4) Connector Layout with part position (Inverter Board).....97

5-1) PCB Layout with part position



1. DC12V, 5V, GND supplied from SMPS PCB (Not Used)
2. Circuit for controlling Step-Valve (3-Way Valve) * Option
3. FAN MOTOR control part : To supply the power from 8.3V ~ 12V according to the motor types. (F,R,C,ICE)
4. EEPROM : Save and record every kinds of data.
5. Transmit inputted signals from every sensor into MICOM after eliminate the noise.
6. Micom : control the refrigerator Ceramic resonator : generate the basic frequency of Micom operation. Reset IC : make Micom reset if input voltage of Micom is detected less than the specified voltage
7. PLC input/output
 - PLC (Power Line communication) * Option (PLC module is not inserted unless specified occasion)
8. Operate ICE-MAKER, supply power to MOTOR, and sense the variation of switch.
9. Main Micom ↔ Panel Micom serial communication circuit – Dispenser option input part (Water & Cover Ice route switch)
10. PANTRY Room display control part : display LED, detect KEY state.
11. Control PANTRY Room damper & Damper heater
12. Water Tank Heater Controls (also controls other options)
13. LED LAMP Control Circuit (F,R room Lamp)
14. Relay parts that controls AC load and receives Micom operating signal through Sink IC.
15. Connector with AC load
 - a. Diode option setting area
 - b. Inverter COMP controlling signal
 - c. Flow Sensor controlling signal


5-2) PCB Layout with part position (Inverter Board)



1. PCB Power Supply : From the SMPS circuit, it supplies 15V and 5V for the Main PBA control and supplies 15V and 5V to the Inverter circuit for the Compressor control.
2. Inverter Control Circuit : Fridge Compressor Control Circuit.
3. COMP Driving / Feedback Circuit
It receives the COMP operation signals from the Main PBA and feedbacks the inverter errors to the Main PBA.
4. BOOTSTRAP Charger : It is an independent power circuit for the driving of the IMP High-Phase IGBT.
5. Current Pickup Circuit : It pickups the currents taken by the Shunt resistance and does the PWM DUTY control.
6. IPM (FNE41060)
7. Micom (MN103SFC2D)

5-3) Connector Layout with part position (Main Board)

5-3-1. RF263TEAE**, RF263BEAE**



PCB DIAGRAM

5-4) Connector Layout with part position (Inverter Board)

AC 115V

- ①② 13.2V ③ 5V
- ④⑤ GND ⑥ RPM ⑦FB




POWER(115V) OLP

⑤W ③V ①U


6. WIRING DIAGRAM

6-1) Model : RF263TEAE**, RF263BEAE**




7-2) Whole block diagram

7-2. MODEL : RF263TEAE**, RF263BEAE**



7-3) CIRCUIT DIAGRAM

7-3-2. INVERTER





272, Oseon-Dong, Gwangsan-Gu,
Gwangju-City, Korea, 506-253
TEL : 82-62-950-6193, 6896
FAX : 82-62-950-6829

For the latest information, Please access to our service web site

- Europe, Mid east, Africa : <http://gspn1.samsungcsportal.com>
- Asia : <http://gspn2.samsungcsportal.com>
- North America : <http://gspn3.samsungcsportal.com>

– This Service Manual is a property of Samsung Electronics Co., Ltd.
Any unauthorized use of Manual can be punished under applicable
International or domestic law.